

Remote Shipping

11.1

January 2026

DOCUMENT ACCESS

Public

DISCLAIMER

The contents of this document are under copyright of Critical Manufacturing S.A. it is released on condition that it shall not be copied in whole, in part or otherwise reproduced (whether by photographic, or any other method) and the contents therefore shall not be divulged to any person other than that of the addressee (save to other authorized offices of his organization having need to know such contents, for the purpose for which disclosure is made) without prior written consent of submitting company.

Remote Shipping

Estimated time to read: 4 minutes

The Remote Shipping functionality is associated with the **Material** and **Container** entities. Its usefulness is visible when there is a need to move or ship **Materials**, and sometimes their **Containers**, from one site to another.

Note

The sites that you use must be connected to each other.

This document will guide you through the setup and usage of the Remote Shipping functionality.

Overview

Remote Shipping comprises sending **Materials**, and optionally their **Containers**, from one Critical Manufacturing MES instance to another. Critical Manufacturing MES supports **Material** and **Container** loops, in other words, **Materials** and **Containers** that are shipped and then returned to the original sending system.

The remote shipping process uses an Integration Entry mechanism through a generic Integration Handler, which is configured to handle Integration Entries with messages related to remote shipping and acknowledgement through the **Process Remote Material Shipment** DEE action (provided out of the box).

Info

For more information, see [MES Integration](#).

Remote Shipping Material

The remote shipping material process works in the following manner:

1. You must ship the material in Critical Manufacturing MES (similar to the local shipping process).
2. The local Critical Manufacturing MES triggers a new Integration Entry with InTransit **Material**, and optionally **Container**, information.
3. The Integration Entry at the source triggers a new Integration Entry in the target system through a web API based on the remote site information.

Remote Receiving Material

The remote receiving material process works in the following manner:

1. The target Critical Manufacturing MES system reads the information from its Integration Entries. It then creates a temporary remote export object with the **Material**, and optionally **Container**, information.
2. In the Facility View you select a **Material** from the Remote field of Materials to Receive and then select **Receive** on the top ribbon.

3. The **Receive** operation will create a **Material**, and optionally **Container**, for its own remote export object and will trigger an acknowledgement message for the source system by using the Integration Entries mechanism.
4. The source system will receive and terminate the **Material**, and optionally **Container**, when it processes the acknowledgement message.

Configuring Remote Shipping

To configure remote shipping between two Critical Manufacturing MES instances, follow the information below.


For the purpose of this tutorial, the following environments were used:

- <https://source-system.dev>
- <https://target-system.dev>

Target System

Ensure that the remote shipping infrastructure is up and running and that there is connectivity between the two different sites. This should include network, firewall and security.

Configure the **Site** for the source system (example: AP-Site-01) according to the [Configure Remote Site](#) instructions:



Tip

Remote Export Address - This is the URL address when you log on to the system (see the browser address bar).

Remote Export Tenant - Tenant name available on the address bar when you are in the login screen of the MES system.

Remote Export Token - Token created in the remote environment according to the [Creating Access Tokens for a User](#) instructions.

Create a local **Facility** to receive shipped **Materials** with no **Site** associated:

Create Facility

1 GENERAL DATA

General Data

Name:

AP-Facility-02

Description:

AP-Facility-02

* Type:

Standard

×

▼

Data Group:

▼

Information

* Display Order:

0

Default Calendar:

Standard

×

Site:

Site

Remote:

Terminate on Ship to This Facility:

Comments:

Cancel

Create

Source System

Configure the **Site** for the target system (example: AP-Site-02) according to the [Configure Remote Site](#) instructions:

https://vm-prod-clmft.criticalmanufacturing.com/2023/1/Entry/Site/25040900002000002/View/Details

Administration

Business Data

Manufacturing

Maintenance

Quality

Planning and Logistics

Business Intelligence

Automation

Data Platform

Apps

AP-Site-02

General Actions

AP-Site-02 (Active)

DETAILS

Site

Name: AP-Site-02

Description: AP-Site-02

Universal State: Active

Enterprise: AP-Enterprise-01

Remote: Yes

Remote Export Address: https://target-system.dev

Remote Export Tenant: MesDevelopment

Remote Export Token: [redacted]

DETAILS

FACILITIES

ATTACHMENTS

Create a remote **Facility** with the previously created **Site** according to the [Configure Remote Facility](#) instructions:

AP-Facility-02

Refresh

Edit

More

GeneralActions

AP-Facility-02 (Active)

DETAILS

Facility



Name: AP-Facility-02

Description: AP-Facility-02

Type: Standard

Universal State: Active

Information

Display Order: 0

Default Calendar: Standard

Site: AP-Site-02

Remote: Yes

Terminate On Ship to This Facility: No

DETAILS

AREAS


SHIPPING INFORMATION

ATTACHMENTS

i Info

The remote Facility must have the same name as the corresponding Facility in the target system.

In the source system from a local **Facility**, go to the **Shipping Information** section and associate the remote **Facility** to allow shipping:



FACILITY	DESCRIPTION	TYPE	REMOTE
AP-Facility-02	AP-Facility-02	Standard	✓

Mark as many **Steps** as intended with the Allow Shipping property.

Ship **Material** normally and specify whether **Containers** should also be shipped.

Info

For the Shipping process to succeed, the Product must exist in both the local and remote Facilities.

Info

If the Material has user-defined attributes, they will only be created in the remote Facility if the same attributes (same name and same data type) exist in the remote Facility.



Legal Information

Disclaimer

The information contained in this document represents the current view of Critical Manufacturing on the issues discussed as of the date of publication. Because Critical Manufacturing must respond to changing market conditions, it should not be interpreted to be a commitment on the part of Critical Manufacturing, and Critical Manufacturing cannot guarantee the accuracy of any information presented after the date of publication. This document is for informational purposes only.

Critical Manufacturing makes no warranties, express, implied or statutory, as to the information herein contained.

Confidentiality Notice

All materials and information included herein are being provided by Critical Manufacturing to its Customer solely for Customer internal use for its business purposes. Critical Manufacturing retains all rights, titles, interests in and copyrights to the materials and information herein. The materials and information contained herein constitute confidential information of Critical Manufacturing and the Customer must not disclose or transfer by any means any of these materials or information, whether total or partial, to any third party without the prior explicit consent by Critical Manufacturing.

Copyright Information

All title and copyrights in and to the Software (including but not limited to any source code, binaries, designs, specifications, models, documents, layouts, images, photographs, animations, video, audio, music, text incorporated into the Software), the accompanying printed materials, and any copies of the Software, and any trademarks or service marks of Critical Manufacturing are owned by Critical Manufacturing unless explicitly stated otherwise. All title and intellectual property rights in and to the content that may be accessed through use of the Software is the property of the respective content owner and is protected by applicable copyright or other intellectual property laws and treaties.

Trademark Information

Critical Manufacturing is a registered trademark of Critical Manufacturing.

All other trademarks are property of their respective owners.