How to: Replace an Assembled Material

1. Go to the Business Data menu.



2. Select the Material entity.



3. Select your desired Material.



4. Select the Assemble button.



5. Select the Replace Assembled option.



6. Under the Replace Assembled Material wizard you can manage each sub-product quantity to be replaced.

For more information, see Replace Assembled Material - Critical Manufacturing Documentation Portal



7. Indicate the quantities to be replaced for each sub-product.



8. Select the Next button.



9. For each sub-product indicate the amount of quantity of each available material to replace.

In some situations, you can indicate a different material that satisfies the conditions of the original material as a replacement.



10. Select the Replace button.


Critical manufacturing
Administration
Business Data
Manufacturing
Maintenance
Quality
Planning and Logistics
Business Intelligence
Automation
Data Platform
Apps
CMF102xQA
MAT_CHK01
Replace Assembled Material
BOM
REPLACEMENT
MAT_CHK01 (InProcess) / Belgas [A] (Belgas Cookies) / Mixing / 20 Kg
BOM Materials 02 [A] (ExplicitLongRunning)
BOM
PRODUCT
REPLACED QTY.
AMMONIUM PHOSPHATE [A] (AMMONIUM PHOSPHATE)
Ammonium Phosphate [A] (Ammonium Ph... 1 of 1 Kg
No Location / No Position (0 Kg)
AmmoniumPhosphate-01 1 Kg
Product Details
Source Product:
Ammonium Phosphate [A]
Description:
Ammonium Phosphate
Location:
Position:
Quantity To Be Replaced:
1 Kg
MORE DETAILS
Comments:
Cancel
Back
Replace