


How to: Track-Out

1. Go to the Business Data menu.




2. Select the Material entity.




3. Select a Material.

The material selection can be done this way, or through Step or Resource View.




4. Select a the Track-Out button.

This option is available in any View, as long as the Material is in the In Process state.



5. Select the Next button.



6. Select the Track-Out button.

