



How to: Scale an object in FabLive


1. Double Click the object to select it.



2. Select the Scale option.



3. Drag the handles (gizmos) around the object to resize it.



4. Alternatively, edit its scale in the Selection Properties panel.

