

How to: Make Container Available/Unavailable

11.1

January 2026

DOCUMENT ACCESS

Public

DISCLAIMER


The contents of this document are under copyright of Critical Manufacturing S.A. it is released on condition that it shall not be copied in whole, in part or otherwise reproduced (whether by photographic, or any other method) and the contents therefore shall not be divulged to any person other than that of the addressee (save to other authorized offices of his organization having need to know such contents, for the purpose for which disclosure is made) without prior written consent of submitting company.

How to: Make Container Available/Unavailable

1. Go to the Business Data menu.



2. Select the Container entity.




3. Select the desired Container.

Container

DEFAULT QUERY ▼

NAME	DESCRIPTION
Container001	Container001 De
Container002	Container002 De
Container003	Container003 De
Container004	Container004 De
Container005	Container005 De

4. Select the Make Available button in case of the Container being defined as Unavailable.



5. Upon confirmation select the Make Available button.

For more information, see [Make Container Available - Critical Manufacturing Documentation Portal](#)

Make Container Available

Container002 (Unavailable)

Type: General

Description: Container002 Description

Facility: Cookie Factory


Used Positions: 0

Total Positions: 100

Comments:


Cancel Make Available

6. Select the Make Unavailable button in case of the Container being defined as Available.



7. Upon confirmation select the Make Unavailable button.

For more information, see [Make Container Unavailable - Critical Manufacturing Documentation Portal](#)





Legal Information

Disclaimer

The information contained in this document represents the current view of Critical Manufacturing on the issues discussed as of the date of publication. Because Critical Manufacturing must respond to changing market conditions, it should not be interpreted to be a commitment on the part of Critical Manufacturing, and Critical Manufacturing cannot guarantee the accuracy of any information presented after the date of publication. This document is for informational purposes only.

Critical Manufacturing makes no warranties, express, implied or statutory, as to the information herein contained.

Confidentiality Notice

All materials and information included herein are being provided by Critical Manufacturing to its Customer solely for Customer internal use for its business purposes. Critical Manufacturing retains all rights, titles, interests in and copyrights to the materials and information herein. The materials and information contained herein constitute confidential information of Critical Manufacturing and the Customer must not disclose or transfer by any means any of these materials or information, whether total or partial, to any third party without the prior explicit consent by Critical Manufacturing.

Copyright Information

All title and copyrights in and to the Software (including but not limited to any source code, binaries, designs, specifications, models, documents, layouts, images, photographs, animations, video, audio, music, text incorporated into the Software), the accompanying printed materials, and any copies of the Software, and any trademarks or service marks of Critical Manufacturing are owned by Critical Manufacturing unless explicitly stated otherwise. All title and intellectual property rights in and to the content that may be accessed through use of the Software is the property of the respective content owner and is protected by applicable copyright or other intellectual property laws and treaties.

Trademark Information

Critical Manufacturing is a registered trademark of Critical Manufacturing.

All other trademarks are property of their respective owners.