



How to: Download the Automation Manager as a zip


1. Go to the Automation Manager



2. Select the Automation Manager you want to download




3. Select Download




4. You can either download with your user permissions or another user


We will change our user to be able to download




5. Select Administration




6. Select Security



7. Select Users



8. Type in highlight



9. Select admin

▼ DETAILS

General Data

 Account: admin

Name: admin

Email Address: admin@criticalmanufacturing.com

Primary Role:

Integration User: ✕ No

Enabled: ✓ Yes

Auto-Lock TimeOut:

PIN: ****

Token:

10. Select Edit

 Refresh  Edit  Delete  Export  More

admin (Created)

▼ DETAILS

General Data

 Account: admin

Name: admin

Email Address: admin@criticalmanufacturing.com

Primary Role:

Integration User: ✕ No


11. Select highlight

* Name:	admin
Email Address:	admin@criticalmanufacturing.com
Primary Role:	
Integration User:	☐
Enabled:	☒
Auto-Lock Timeout:	seconds
PIN:	
Token:	

12. Select highlight


* Name:	admin
Email Address:	admin@criticalmanufacturing.com
Primary Role:	
Integration User:	☒
Enabled:	☒
Auto-Lock Timeout:	seconds
PIN:	
Token:	

13. Select Save



A screenshot of a web application form. It features several empty input fields stacked vertically. At the bottom right, there are two buttons: 'Cancel' and 'Save'. The 'Save' button is highlighted with a yellow rectangular box. A small circular icon with a pencil is visible to the right of the 'Save' button.


14. Select the Automation Manager




A screenshot of the 'Automation Manager' interface. The top navigation bar shows 'JRTTest' and 'admin'. Below the navigation bar, there are icons for 'Refresh', 'Edit', 'Delete', 'Export', and 'More'. The main content area displays the details for the 'admin' user, including a 'DETAILS' section with 'General Data'.

Account: admin
Name: admin
Email Address: admin@criticalmanufacturing.com
Primary Role:

15. Select highlight



16. Select Download



17. Select Download to finish the process

It will trigger the download of a zip file

