


How to: Change Resource State


1. Go to the Business Data menu.



2. Select the Resource entity.




3. Select the Resource.



| NAME | DESCRIPTION |
|----------|-------------------|
| Baker-01 | Baker-01 Resource |
| Baker-02 | Baker-02 Resource |


4. Select the Change State button.

For more information, see [Change Resource State - Critical Manufacturing Documentation Portal](#)



Baker-01 (Active)

DETAILS

| Resource | Information |
|--|--|
|  <p>Name: Baker-01</p> <p>Description: Baker-01 Resource</p> <p>Type: Standard</p> <p>Universal State: Active</p> | <p>Area: Cook</p> <p>Priority: 5</p> <p>Display order: 200</p> <p>Vendor: Gene</p> |

5. Select the needed State followed by Change State.

☰

Critical manufacturing

Administration

Business Data

Manufacturing

Maintenance

Quality

Planning and Logistics

Business Intelligence

Automation

Data Platform

Apps

Baker-01

×

Change State

STATE SELECTION

Baker-01 (Up) / SEMI E10 > Standby

▼

New State:

✓

Standby (current)
to Standby (current)

Nonscheduled
Standby to Nonscheduled

Scheduled Down
Standby to Scheduled Down

Engineering
Standby to Engineering

Productive
Standby to Productive

Unscheduled Down
Standby to Unscheduled Down

Comments:

Cancel

Change State