How to: Manage BOM Items

1. Go to the Business Data menu.

2. Select the BOM entity.


3. Select the BOM you need.

(BOMTest [A] for this example)

4. Select the BOM ITEMS section.

5. Select Manage.

For more information, see Manage BOM Items - Critical Manufacturing Documentation Portal ⊞

6. Add, remove or re-order as needed.

For this example, we are going to Add.

7. Enter the necessary information and select Next.

8. Add the necessary information for the Substitute Products if needed and then select Update.