



**Critical**  
manufacturing  
an ASM PT company

# How to: Set a Connect IoT Repository

## 11.3

April 2026

### DOCUMENT ACCESS


Public

### DISCLAIMER


The contents of this document are under copyright of Critical Manufacturing S.A. it is released on condition that it shall not be copied in whole, in part or otherwise reproduced (whether by photographic, or any other method) and the contents therefore shall not be divulged to any person other than that of the addressee (save to other authorized offices of his organization having need to know such contents, for the purpose for which disclosure is made) without prior written consent of submitting company.

## How to: Set a Connect IoT Repository


### 1. Go to MES




### 2. Select Administration




### 3. Select Configuration



#### 4. Select Cmf




#### 5. Select System



The screenshot shows a navigation pane on the left with 'All Entries' at the top. Below it, a breadcrumb path shows '< ROOT'. The main list contains three entries: 'Cmf', 'Guis', and 'System'. The 'System' entry is highlighted with a yellow box. The right pane displays 'General Data' for the selected entry, showing a wrench icon, Path: /Cmf/, Name: Cmf, Type: Value, and Confidential: X No. Below this, there is a 'CHILD ENTRIES' section and an 'Entries (2)' table with two rows: /Cmf/Guis/ and /Cmf/System/.

PATH
/Cmf/Guis/
/Cmf/System/


## 6. Select Configuration




The screenshot shows the navigation pane with 'All Entries' at the top. The breadcrumb path is '< CMF'. The main list contains two entries: 'System' and 'Configuration'. The 'Configuration' entry is highlighted with a yellow box. The right pane displays 'General Data' for the selected entry, showing a wrench icon, Path: /Cmf/System/, Name: System, Type: Value, and Confidential: X No. Below this, there is a 'CHILD ENTRIES' section and an 'Entries (1)' table with one row: /Cmf/System/Configuration/.

PATH
/Cmf/System/Configuration/

## 7. Select ConnectIoT




## 8. Select RepositoryType




## 9. Set the Repository Type


The repository type settings can be either a **Directory** or **NPM**



## 10. Select RepositoryLocation



## 11. Set either the NPM URL or the path to the Directory



The screenshot displays the Configuration management interface. The main content area shows a configuration entry with the following details:

- General Data:**
  - Path: `/Cmf/System/Configuration/Connect/RepositoryLocation/`
  - Name: `RepositoryLocation`
  - Type: `String`
  - Value:
  - Confidential:  No
- Information:**
  - Created by: `System`
  - Created on: `12/30/2018 10:04 PM`
  - Modified by: `admin`
  - Modified on: `11/02/2023 09:17 AM`

Below the configuration entry, there is a section for CHILD ENTRIES, which is currently empty. The interface includes a search bar and a table with columns for PATH, NAME, and VALUE. The table shows "No data to show".

At the bottom right of the table area, there is a pagination control showing "Page 1 of 1 (0 Records)" and "Rows per Page: 25".



# Legal Information

## **Disclaimer**

The information contained in this document represents the current view of Critical Manufacturing on the issues discussed as of the date of publication. Because Critical Manufacturing must respond to changing market conditions, it should not be interpreted to be a commitment on the part of Critical Manufacturing, and Critical Manufacturing cannot guarantee the accuracy of any information presented after the date of publication. This document is for informational purposes only.

Critical Manufacturing makes no warranties, express, implied or statutory, as to the information herein contained.

## **Confidentiality Notice**

All materials and information included herein are being provided by Critical Manufacturing to its Customer solely for Customer internal use for its business purposes. Critical Manufacturing retains all rights, titles, interests in and copyrights to the materials and information herein. The materials and information contained herein constitute confidential information of Critical Manufacturing and the Customer must not disclose or transfer by any means any of these materials or information, whether total or partial, to any third party without the prior explicit consent by Critical Manufacturing.

## **Copyright Information**

All title and copyrights in and to the Software (including but not limited to any source code, binaries, designs, specifications, models, documents, layouts, images, photographs, animations, video, audio, music, text incorporated into the Software), the accompanying printed materials, and any copies of the Software, and any trademarks or service marks of Critical Manufacturing are owned by Critical Manufacturing unless explicitly stated otherwise. All title and intellectual property rights in and to the content that may be accessed through use of the Software is the property of the respective content owner and is protected by applicable copyright or other intellectual property laws and treaties.

## **Trademark Information**

Critical Manufacturing is a registered trademark of Critical Manufacturing.

All other trademarks are property of their respective owners.